

Dunestrider's Organizer

LEGEND



Please, remove protective layer from the acrylic sheet with a box cutter or a thin knife.




HDF (ХДФ)




Acrylic (акрил)





Plywood (фанера)





A




B




C




D




E




Attention! In part E, the boxes' details E1 and E6 should be combined in these exact pairings.
Зуважте! У коробках Е деталі Е1 та Е6 мають збиратись відповідними за малюнком парами.





F



Attention! Put all the tablet jumper parts, marked with a cross, into the plywood part of the tablet.
Зуважте! Прикріпіть перемички стороною з хрестиком до фанерної частини планшету.



Attention! Handle construction with care, as acryl is a fragile to push material.
Зуважте! Обережно поводьтеся з планшетом, оскільки акрил є крихким матеріалом.



LET'S MAKE GAMING MORE EXCITING TOGETHER!